


PiGo™

www.DesignSpark.com/PiGo

Modular Expansion System for Raspberry Pi Motor module

User manual




Overview

PiGo motor module is a module that can be attached to any of the PiGo module sockets (A, B, C or D). The module contains DRV8842 motor driver IC, which contains two half-bridges. The IN1 and IN2 input pins of the driver directly control the state of the OUT1 and OUT2 outputs of the driver. The outputs are powered from the V_{IN} power supply (DC power supply input jack) of the PiGo board.

PiGo motor module also contains a current limit adjustment trimmer, which is used to define the maximum output current.

Architecture and physical specification

PiGo motor module layout



Electrical specifications

PiGo motor module is powered from both 3.3 V and V_{IN} (PiGo DC power supply) power supply, provided by the PiGo base board.

The following table shows basic parameters of the motor driver IC used. For more details, users should study the datasheet of the device.

Motor driver (DRV8842)

Input voltage	12 V
Maximum output current	5 A peak



Module connectors

PiGo motor module can be attached to any of the PiGo module sockets (A, B, C or D). It has the following connections:

Left socket		Right socket	
Pi _{SDA}	NC	Power Supply ground	GND
Pi _{SCL}	NC	Raspberry DC power supply	V _{IN}
Pi _{RX}	NC	3.3 V power supply	V _{3.3 V}
Pi _{TX}	NC	NC	V _{5 V}
U _{IO2A/B/C/D}	OUT 2 (PWM mode)	OUT1 (digital mode)	U _{IO3A/B/C/D}
EXT10/12/14/16	NC	NC	P _{IO1A/B/C/D}
EXT9/11/13/15	NC	NC	P _{IO2A/B/C/D}
EXT2/4/6/8	IN2 input	NC	P _{IO3A/B/C/D}
EXT1/3/5/7	IN1 input	NC	P _{IO4A/B/C/D}
U _{IO1A/B/C/D}	OUT 1 (PWM mode)	OUT2 (digital mode)	U _{IO4A/B/C/D}
V _{5 V}	NC	NC	CS _{A/B/C/D}
V _{3.3 V}	Same as V _{3.3 V} right	NC	Pi _{SCLK}
V _{IN}	Same as V _{IN} right	NC	Pi _{MISO}
GND	Same as GND right	NC	Pi _{MOSI}

Note: NC stands for Not Connected – this signal is not used by the module.

PiGo motor module can be inserted in two different configurations into the module sockets on the PiGo base board, providing two different mode of operation.

Digital Mode ('aligned')



PWM Mode ('rotated 180°')



In digital mode, External GPIO signals are used to control the direction of the connected motor. Only three different speeds are available: -100%, 0% and +100%.

In PWM mode, P_{IO1}{A/B/C/D} and P_{IO2}{A/B/C/D} pins on the PiGo board must be connected to buffered IO pins 1 and 2. In this mode, motor speed can be adjusted in multiple steps between -100% and +100%. The exact number of steps depends on the PWM frequency selected.

Module usage

PiGo motor module can be accessed using the `ModuleMotor` class from the PiGo Python library.

Function and description **ModuleMotor** – Initialize PiGo motor module class

Arguments	PiGoBoardObject : reference to the PiGo board object SocketID : Socket on the PiGo base board, where the PiGo motor module is attached to Mode : 0 (digital mode) or 1 (PWM mode) PWMfreq : PWM frequency (default: 1000)
Returns	Instance of the motor module class
Example	<pre>brd = PiGoBoard() # PiGo Motor module is connected to socket 'A' motor = ModuleMotor (brd, "B", 0)</pre>

Function and description **setOutput** – Set the output power

Arguments	power : motor power (-1 to 1)
Returns	none
Example	<pre>brd = PiGoBoard() # PiGo Motor module is connected to socket 'A' motor = ModuleMotor (brd, "B", 0) # Full power to one direction motor.setOutput(1) # Full power to other direction motor.setOutput(-1) # Stop motor.setOutput(0)</pre>

Frequently asked questions

None yet



Module schematics

